



LONG#2

NABAKEM LONG#2 (Heavy Duty Rust-Preventer)

- Packaging Unit :**
- Aerosol 420ml/can, 20cans/Box
 - Bulk 20ℓ/Pail

LIST

Features

- Powerful antirust agent (indoors : 3 years, outdoors: 2 years)
- Powerful wax-type film formation
- Excellent water displacement
- Rustproofing : Thick wax-type film protects equipment against moisture, acid, alkali and salinity or their evaporation, maintaining strong antirust effects.

The product maintains antirust effects for three years outdoors and two years indoors, and is used for vessels, airplanes and chemical plants.

- Lubrication : Excellent antiabrasion, antifricition and heat-resistance.

Excellent permeability making it penetrate into fine cracks to show antirust and lubrication effects.

Also, with excellent adhesiveness, it is not peeled easily, protecting equipment against water or sea water.

- Water displacement : Low surface tension and high permeability.

High water repellency and water displacement creating excellent insulation effects.

Excellent electric property making it ideal for protection of electric system.

- Stability : As it does not silicon except chloric solvents, it is not harmful to plastics, rubber, paint, textile, wire and plated area.

Green product without using freon gas.

It can be used while equipment operates.

Easy-to-use aerosol product.

Uses

- Equipment, tools, engine and military supplies for long-term keeping indoors and outdoors
- Vessels, chemical plants and airplanes under hard conditions like moisture, salinity, acid and alkali
- Automobiles, snowplow, military equipment, hoist, agricultural machinery and railway cars easily exposed to corrosion
- Outdoor electry system, irrigation facility, military transportation vehicles and their electric systems.

How to Use

- NABAKEM LONG#2: aerosol product and liquid product
- Shake aerosol product before use.

Spray it evenly to the target objects with 20~30cm away from it.

- Apply bulk product by using brush or roller.
- Or you can dip the target object to use the product.

Cautions

- Remove the dust, dirt, rust and scale on the surface of target object before use
- Keep it in the place above 40°C.
- Provide ventilation when using it closed room.