





pmc-3

NABAKEM PMC-3(Powerful Mold Cleaner)

Packaging Unit: Aerosol 420ml/can, 20cans/box

Features

• Excellent permeability and powerful cleasing : With excellent cleansing in good harmony with quick vaporization, penetrates deep into the complex mold.

Perfect removal of oil, grease, dust, carbon, injection molding residues without damaging cleaning target.

- Residues : Completely vaporized pmc-3 has high density and low surface tension.
- It removes the contaminants of complex mold and precision equipment perfectly.

As it does not leave residues, separate washing is not required.

Also, it can keep cleaning target clean.

It does not attract dust or static electricity, nor contain carbon tetrachloride, silicon and petrolic solvents.

• Saftey : Chemcally stable and low-toxic.

It does not dischlorate and corrode mold, precision machinery and its parts, showing high stability.

With excellent chemical stability, pmc-3 can be preserved for a long time.

• Non-petrolic and non-freonic solvent: Orgainic solvents (toluene, benzene etc.) and freonic cleaners toxic and harmful to human body and environment are not contained.

Uses

- · Cleaning of injection molding residues, and carbons
- Degreasing of all precision equipment and metals
- Cleaning of precise machinery, aircraft instrument and electronic equipment
- · Cleaning and degreasing of all metal parts and equipment

How to Use

How to use : Spray it 20~30cm away from target object.

Cautions

- Ventilation required during use. Avoid long-time inhalation.
- Avoid long-time skin contact.
- Test it before using it to rubber, plastic, and painted surfaces
- Keep it in well-ventilated cool place below 40℃.