



S-830

Silicone Conformal Coating S-830

Packaging Unit : Aerosol 420ml/can, 20cans/Box
Liquid 15kg/Tin Can

Features

- Excellent ozone-resistance, arc-resistance, heat-resistance, and chemical-resistance
- Excellent adhesion and surface polishing
- Excellent shock-resistance, antiabrasion and vibration-resistance.
- Strong acid-resistance. No change in hardening

Uses

P.C.B
Coil
Solenoids
Connectors
Control Box
Transformers
Motors,
Generator
Toys
Industrial Arts
Woods etc.

How to Use

- Clean the dust, oil contents and grease on the surface
- Shake up and down lightly before use
- Spray twice or three times to make thick film formed.
- Spray it about 20~30cm away from target object

Cautions

- Keep it away from your children.
- This flammable product uses high-pressure gas.
Comply with following cautions.
 - 1 .Do not use it toward fire.
 2. Do not use near heater or stove.

3. Do not use in the room using fire.
4. Do not keep it in the place above 40°C.
5. Provide ventilation to use it in the closed room.
6. Do not throw it away into fire.
7. Punch the can to throw it away.
8. Do not keep it in the closed place.
9. Spraying may not work well below 5°C.